

1. Push the 2 ends of the gasket together to form one solid loop.
2. Line it up with the centre of the back of the Trim Tote (the side that will be inserted into the M108).



3. Push the gasket onto the back rim of the Trim Tote.
4. Moving from back to front, continue pushing the gasket onto the Trim Tote, working on both sides simultaneously until it is securely in place around the entire rim.



5. Slide the Trim Tote into the opening shown at right.
6. Lock in place by lifting both blue levers on either side. Push arms inwards and up until they click into place.

