


# TUMBLER & BRUSH WASHER

The Mobius Tumbler & Brush Washer provides an automated way to clean these components quickly and efficiently.

STEP 01.



Start by removing the right locking ring metal ring from the tumbler frame.

STEP 02.




Drape your tumbler over the tumbler frame, being careful not to snag the cables.

STEP 03.




Place the right locking ring back onto tumbler frame.

STEP 04.




Lock the tumbler cap in place by fitting it into the cutouts on the locking ring and rotating it.

STEP 05.



Lock the bottom tumbler cap into the bottom ring in the same fashion.

STEP 06.



Use your hand to keep the tumbler from slipping out of the locking ring and turn the knob on the right locking ring clockwise. You should see the tumbler cables start to tighten.

STEP 07.




Place the tumbler frame into the washing tub by setting the left side down...

STEP 08.




...and leaving the right side to rest on the metal extension.

**STEP 09.**




On the left side, make sure the small hole lines up with the driving pin.

**STEP 10.**




Lift and slide the tumbler frame onto the motor shaft.

**STEP 11.**



When you do this, the tumbler frame extension on the right side will slide into place.


**STEP 12.**



Insert your dirty brush into the clips on the lid in the same way you clip it into the lid of the M108S.


Fill the tub with warm water and degreaser. Close the lid. You're now ready to start washing.

**STEP 13.**




Press the green start button to begin the washing process.

**STEP 14.**



When you push the emergency stop button, you won't be able to press the start button again. This is a safety feature. You'll need to rotate the e-stop to the right to disengage it first, and then push the start button.

**STEP 15.**



To end a cycle, simply press the smaller red stop button. The tumbler will rotate in the soapy solution and clean the brush anchored in the lid at the same time.

To remove the components, follow the steps below.


# TUMBLER & BRUSH WASHER

STEP 01.



Start by unplugging the machine and locking all 4 of the castors.

STEP 02.




Open the lid and remove the tumbler frame insert by lifting and pulling slightly to the right side

STEP 03.




Set it on the ground so you can access the metal handle

STEP 04.



Turn the tightening knob counterclockwise to undo the tension in the tumbler.

STEP 05.




Rotate the tumbler end cap to detach it from the right locking ring.

STEP 06.




Next detach the left tumbler end cap from the left locking ring.

STEP 07.



Slide the tumbler off the frame.

STEP 08.



Remove the brush by unclipping it at each end.